

Note!

Before installing this product, check the contents of the kit. If anything is missing, please contact an Öhlins dealer.

Kit Contents

Description	Part No	Pcs
Shock absorber	YA 856	1
Bracket, reservoir	60006-23	1
Clamp bracket	03102-15	1
Screw M6x12	01046-36	2
Screw M6x14	00382-16	1
Screw M8x40	05404-16	2
C-spanner	60710-01	2
Sticker set	10207-01	1
Owner's Manual	07241-02	1

• Note!

Please note that this image is a general representation of the product and may differ slightly from your product.

Note!

Please note that during storage and transportation, especially at high ambient temperature, some of the oil and grease used for assembling may leak and stain the packaging. This is in no way detrimental to the product, wipe off the excessive oil/grease with a cloth.

Note!

Before installing this product, check the contents of the kit. If anything is missing, please check an Öhlins dealer.

Before installing this product, read the Öhlins Owner's Manual. The shock absorber is an important part of your vehicle and will affect the stability.

Shock Absorber for YAMAHA MT-15



Mounting Instructions



▲ Warning!

It is advisable to have an Öhlins dealer install the shock absorber.

Marning!

If working on a raised vehicle, ensure it is securely supported so that it will not tip over.

Note!

Before mounting this product clean the vehicle thoroughly.

Note!

When working on this product, always see the Vehicle Service Manual for vehicle specific procedures and important data.

Note!

Lower the vehicle so that the suspension is slightly compressed before tightening the screws.




Caution!


Ensure that all screws are tightened to the correct torque and that nothing fouls or restricts movement of the shock absorber when the suspension is fully compressed or extended.

Put the motorcycle on a work stand so that the rear wheel barely touch the ground.


Remove the rear seat by using the ignition key. Make sure that the motorbike is in a stable position.



2 Take off the footpeg by removing 2 screws.




3 Take off the linkage by removing 1 screw (1). Remove the shock absorber by removing the upper and lower bolt (2,3).



4

Install the steel plate bracket between the footpeg and the frame by the 2 screws 05404-16. Tighten as specified in the vehicle service manual.




5

Install the Öhlins shock absorber by tightening the lower and upper mounting screw at a torque value as specified in the vehicle service manual.

Fix the clamp bracket to the steel plate bracket by the 2 screws 01046-36.

Slide the reservoir into the clamp bracket, then tighten it.

Reverse all procedures.



This page intentionally left blank


This page intentionally left blank

This page intentionally left blank

ADJUSTMENTS

▲ Warning!

Before riding, always make sure that the basic settings made by Öhlins are according to recommended Set-up Data. Read about adjustments and setting up in the Öhlins Owner's Manual before you make any adjustments. Contact an Öhlins dealer if you have any questions about setting up.



Shock absorber data

SET-UP DATA

Recommended set-up

Spring

 Part No
 60282-03

 Free spring length
 155 mm

 Spring rate
 90 N/mm

 Preload adjustment range
 3mm-22mm

Öhlins products are subject to continuous improvement and development, therefore, although these instructions include the most up-to-date information available at the time of printing, minor updates may occur.

© Öhlins Racing AB. All rights reserved. Any reprinting or unauthorized use without the written permission of Öhlins Racing AB To find the latest information contact an Öhlins distributor. Please contact Öhlins if you have any questions regarding the contents in this document.

Öhlins Racing AB Box 722 SE-194 27 Upplands Väsby, Sweden Phone +46 8 590 025 00

fax +46 8 590 025 80

Part no. MI_YA856_EN_0 Issued 2018-10-26

